

Benno & Max Stage instructions Challenge Accepted:

<u>Preparations</u>	empty stage with neutral background
Personnel	1x light, sound and video technician
	1x Stage Hand
<u>Stage</u>	Optional: stage stairs in the middle of the audience area
	Optional 1x Hazer
	"At least 3x3x3 meters playing area
	Optimally 6x6x6 meters playing area"
	Table with min. width 150 x 50 cm
	Flipchart min. DinA1
	Cleaning bucket
	Storage space for props in the stage aisles (floor also possible)
Technology	Projector with video screen (9:16 format portrait), min. 2.5 meters high Rear projection (projector behind screen) Videos in portrait format format played by the technician Alternatively also self-luminous LED wall
Lighting	Optional min. 4 Floor Spots rear stage edge, 2 Floor Spots side aisle to illuminate the center of the juggling airspace
	A: Moderation light

	"Stage illuminated white to amber in the middle Backdrop floor spots in the rear area violet/ purple."
	B: Show light
	Entire stage including airspace illuminated Avoid aisles and backdrop lighting where possible White light from the front 60% power (dimmed) (No glare during acrobatics/juggling. Backdrop floor spots at the back in a different color (e.g. alternating blue/red). Stage lighting can be illuminated in colored light.
	C: Challenge light
	Colored lights, entire stage illuminated in white and color. Moving lights like a party atmosphere.
	D: Blue light
	Entire stage illuminated in blue and UV and a little white light. Faces and silhouettes still recognizable.
Sound	2x headsets and receivers
	Handheld microphone (preferably wireless) on a stand at the edge of the stage
	Music system with mp3 player Optionally via AUX/USB or laptop
	QLab file including all necessary audio and video files can be sent in advance by e-mail
	USB/own MacBook will be brought along
Stage Hand	For various setups and dismantling



If you have any questions, please do not hesitate to contact us.

+4917623535507 +4915205107324

BENNO JACOB & MAX FRÖHLICH GBR C/O Melissi | SCHÖNHAUSER ALLEE 99 | 10439 BERLIN **WWW.BENNOUNDMAX.DE**USt.-ID: DE328572878 | IBAN: DE57 1001 0123 2102 4668 55 | BIC: QNTODEB2XXX